CHAPTER 1

Preface

Table of Content

Preface

Table of Content **1-2**
Regulations Information **1-5**
FCC-B Radio Frequency Interference Statement 1-5
FCC Conditions 1-6
CE Conformity 1-6
Safety Instructions **1-7**
Safety Guideline for Using Lithium Battery **1-11**
WEEE Statement **1-15**
Optical Drive Device Notice **1-22**
Trademarks **1-22**
Reversion History **1-22**

Introductions

Manual Map **2-2**
Unpacking **2-3**
Specification **2-4**
Product Overview **2-8**
Top-open View 2-8
Front Side View 2-14

Right Side View 2-17
Left Side View 2-19
Rear Side View 2-21
Bottom Side View 2-22

Getting Started

Power Management 3-2
Connecting the AC Power 3-2
Using the Battery Power 3-4
ECO Engine -- Power Saving Function 3-9
GPU Boost Function 3-11
Power Management in Windows OS 3-13
Energy Saving Tips 3-15
Basic Operations 3-16
Safety and Comfort Tips 3-16
Having a Good Work Habit 3-17
Knowing the Keyboard 3-18
Knowing the Smart Pad 3-25
About Hard Disk Drive 3-32
Using the Optical Drive Device 3-33
Connecting the External Devices 3-36
Connecting the Peripheral Devices 3-36
Connecting the Communication Devices 3-40

Components Replacement and Upgrade 3-43

BIOS Setup

About BIOS Setup 4-2
When to Use BIOS Setup 4-2
How to Run BIOS Setup 4-2
Control Keys 4-3
BIOS Setup Menu 4-4
Main Menu 4-5
Advanced Menu 4-7
Security Menu 4-9
Boot Menu 4-11
Exit Menu 4-12

Regulations Information

FCC-B Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and radiates radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

NOTE

- The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- Shield interface cables and AC power cord, if any, must be used in order to comply with the emission limits.

FCC Conditions

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

CE Conformity

CE This device is in compliance with the essential safety requirements and other relevant provisions set out in the European Directive.

Safety Instructions

- Read the safety instructions carefully and thoroughly.
- All cautions and warnings on the equipment or user's manual should be noted.

Keep the User's Guide that comes with the package for future reference.

Keep this equipment away from humidity and high temperature.

Lay this equipment on a stable surface before setting it up.

The openings on the enclosure are used for air convection and to prevent the equipment from overheating. Do not cover the openings.

- Do not leave the equipment in an unconditioned environment with a storage temperature above 60°C (140°F) or below 0°C (32°F), which may damage the equipment.
- The unit should be operated under maximum ambient temperature of 40°C (120°F).

- Make sure the power voltage is within safety range and has been adjusted properly to the value of 100~240V before connecting the equipment to the power outlet.
- Always unplug the AC power cord before installing any add-on card or module to the equipment.
- Always disconnect the AC power cord or uninstall the battery pack or switch off the wall socket if the equipment would be left unused for a certain time to achieve zero energy consumption.

Never pour liquid into the opening that could damage the equipment or cause an electrical shock.

Place the power cord in a way that people are unlikely to step on it. Do not place anything on top of the power cord.

Always keep the strong magnetic or electrical objects away from the equipment.

- When installing the coaxial cable to the TV Tuner, it is necessary to ensure that the metal shield is reliable connected to protective earthing system of the building.
- Cable distribution system should be grounded (earthed) in accordance with ANSI/NFPA 70, the National Electrical Code (NEC), in particular Section 820.93, Grounding of Outer Conductive Shield of a Coaxial Cable.

- To prevent explosion caused by improper battery replacement, use the same or equivalent type of battery recommended by the manufacturer only.
- Always keep the battery in a safe place.

If any of the following situations arises, get the equipment checked by a service personnel:

- The power cord or plug is damaged.
- Liquid has penetrated into the equipment.
- The equipment has been exposed to moisture.
- The equipment has not worked well or you can not get it work according to User's Manual.
- The equipment was dropped and damaged.
- The equipment has obvious signs of breakage.

Green Product Features

- Reduced energy consumption during use and stand-by
- Limited use of substances harmful to the environment and health
- Easily dismantled and recycled
- Reduced use of natural resources by encouraging recycling
- Extended product lifetime through easy upgrades
- Reduced solid waste production through take-back policy

Environmental Policy

- The product has been designed to enable proper reuse of parts and recycling and should not be thrown away
- Users should contact the local authorized point of collection for recycling and disposing of their end-of-life products.

廢電池請回收

For better environmental protection, waste batteries should be collected separately for recycling or special disposal.

Safety Guideline for Using Lithium Battery

(English) CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the equipment manufacturer. Discard used batteries according to manufacturer's instructions.

(French) (Français) ATTENTION: Il y a danger d'explosion s'il y a remplacement incorrect de la batterie. Remplacer uniquement avec une batterie du meme type ou d'un type équivalent recommandé par le constructeur. Mettre au rebut les batteries usages conformément aux instructions du fabricant.

(German) (Deutsch) VORSICHT: Explosionsgefahr bei unsachgemäßem Austausch der Batterie. Ersatz nur durch denselben oder einen vom Hersteller empfohlenen gleich-wertigen Typ. Entsorgung gebrauchter Batterien nach Angaben des Herstellers.

(Spanish) (Español) PRECAUCIÓN: Peligro de explosión si la batería es reemplazada incorrectamente. Cámbiela solo por la misma o un tipo equivalente recomendado por el fabricante. Descarte usar baterías usadas de acuerdo con las instrucciones del fabricante.

(Italian) (Italiano) ATTENZIONE: Pericolo di esplosione della batteria se sostituita in modo non corretto. Sostituire solo con la stesso tipo o con uno equivalente come indicato nel manuale del produttore. Smaltire le batterie usate come da istruzioni del produttore.

(Russian) (Русский) Внимание: Существует опасность взрыва батареи в случае неправильной замены. Для замены всегда используйте такую же или эквивалентную, рекомендованную производителем оборудования. Следуйте инструкциям производителя при утилизации использованных батарей.

(Turkish) (Türkçe) UYARI: Pil yanlıs yerleştirilirse patlayabilir. Aynı ya da muadili bir pille degistiriniz. Kullanılmış pilleri üreticinin talimatlarına göre degerlendiriniz.

(Greek) (Ελληνικά) ΠΡΟΣΟΧΗ: Κίνδυνος έκρηξης εάν η μπαταρία τοποθετηθεί λανθασμένα. Να αντικαθιστάτε μόνο με τον ίδιο ή αντίστοιχο τύπο με αυτό που συνιστά ο κατασκευαστής του εξοπλισμού. Να απορρίπτετε τις χρησιμοποιημένες μπαταρίες ως απορρίμματα σύμφωνα με τις οδηγίες του κατασκευαστή.

(Polish) (Polski) OSTRZEŻENIE: Nieprawidłowa wymiana może spowodować eksplozję baterii. Zamianę można wykonać wyłącznie na baterię tego samego lub równoważnego typu zalecaną przez producenta urządzenia. Zużyte baterie można wyrzucać zgodnie z instrukcjami producenta.

(Hungarian) (Magyar) VIGYÁZAT: A nem megfelelő akkumul tor haszn lata robban svesz lyes. Kizárólag ugyanolyan, vagy a berendezés gyártója által ajánlott, egyenértékű típust használjon. Az elhasznált akkumulátorokat a gyártó utasításának megfelelően ártalmatlanítsák.

(Czech) (Čeština) UPOZORNĚNÍ: Nebezpečí výbuchu při chybné výměně baterie. Nahraďte pouze stejným nebo ekvivalentním typem doporučeným výrobcem zařízení. Použité baterie zlikvidujte podle pokynů výrobce

(Traditional Chinese) (繁體中文) 注意: 電池若未正確更換，可能會爆炸。請用原廠建議之同款或同等級的電池來更換。請依原廠指示處理廢棄電池。

(Simplified Chinese) (简体中文) 注意: 电池若未正确更换，可能会爆炸。请用原厂建议之同款或同等级的电池来更换。请依原厂指示处理废弃电池。

(Japanese) (日本語) 警告：バッテリーの取り扱いを誤ると、液漏れや破裂などにより生命や財産に重大な影響を及ぼす恐れがあります。指定された型番以外のバッテリーは使用しないでください。バッテリーを廃棄する場合は、各自治体の規則に従って適切に処理して下さい。

(Korean) (한국어) 주의: 배터리를 올바로 교체하지 않으면 폭발할 위험이 있습니다. 타입이 장치 제조업체에서 권장하는 것과 동일하거나 동등한 배터리로만 교체하십시오. 사용한 배터리는 제조업체의 지침에 따라 폐기하십시오.

(Vietnamese) (Tieng Viet) LƯU Ý: Thay thế pin không tương thích có thể dẫn đến nguy cơ bị nổ. Chỉ thay thế bằng pin cùng loại hoặc loại tương ứng khuyên dùng bởi nhà sản xuất thiết bị. Vứt bỏ pin đã sử dụng theo hướng dẫn của nhà sản xuất.

(Thai) (ไทย) ข้อควรระวัง: ถ้าใส่แบตเตอรี่อย่างไม่ถูกต้อง อาจมีอันตรายจากการระเบิดขึ้นได้ ใช้เฉพาะแบตเตอรี่ชนิดเดียวกัน หรือเทียบเท่า ที่แนะนำโดยผู้ผลิตอุปกรณ์เท่านั้น ทิ้งแบตเตอรี่ที่ใช้แล้วตามคำแนะนำของผู้ผลิต

(Indonesian) (Bahasa Indonesia) PERHATIAN: Bahaya ledakan dapat terjadi jika salah memasang baterai. Ganti baterai hanya dengan jenis yang sama atau setara sesuai rekomendasi pabrik peralatan tersebut. Buang baterai bekas sesuai petunjuk pabrik

(Serbian) (Srpski) OPREZ: Ukoliko baterija nije ispravno postavljena, postoji opasnost od eksplozije. Zamenu izvršite koristeći isključivo istu ili ekvivalentnu bateriju koju preporučuje proizvođač opreme. Odbacite iskorišćene baterije u skladu sa uputstvima proizvođača.

(Netherlands) (Nederlands) LET OP: Er is explosiegevaar als de batterij niet goed geplaatst wordt. Uitsluitend te vervangen door een batterij van hetzelfde of een gelijkwaardig type,zoals aanbevolen door de fabrikant. Gooi batterijen weg volgens de plaatselijke instructies.

(Romanian) (Română) ATENŢIE: Pericol de explozie dacă bateria este înlocuită incorect. Înlocuiţi doar cu acelaşi tip sau echivalent recomandat de fabricantul echipamentului. Evacuaţi bateriile folosite conform instrucţiunilor fabricantului.

(Portuguese) (Português) ADVERTÊNCIA: Perigo de explosão se a bateria é substituída incorrectamente. Substitua somente com o mesmo tipo ou equivalente recomendado por o fabricante do seu equipamento. Descarte as baterias utilizadas de acordo com as instruções do fabricante.

(Swedish) (Svenska) VARNING: Explosionsfara vid felaktigt batteribyte. Använd samma batterityp eller en ekvivalent typ som rekommenderas av apparattillverkaren. Kassera använt batteri enligt fabrikantens instruction.

(Finnish) (Suomi) VAROITUS: Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan valmistajan suosittelemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.

(Slovak) (Slovenčina) UPOZORNENIE: V prípade nesprávnej výmeny batérie existuje nebezpečenstvo výbuchu. Vymeňte iba za rovnakú batériu alebo za rovnocenný typ batérie, ktorý odporúča výrobca zariadenia. Batérie zneškodnite podľa pokynov výrobcu.

(Slovenian) (Slovenščina) POZOR: V primeru nepravilne zamenjave baterije obstaja nevarnost njene eksplozije. Baterijo zamenjajte le z enako ali ekvivalentno vrsto, ki jo priporoča proizvajalec. Odpadne baterije odstranite skladno z navodili proizvajalca.

(Danish) (Dansk) ADVARSEL! Lithiumbatteri --- Eksplosionsfare ved fejlagtig håndtering. Udskiftning må kun ske med batteri af same fabrikat og type. Levé det brugte batteri tilbage til leverandøren.

(Norwegian) (Norsk) ADVARSEL: Eksplosjonsfare ved feilaktig skifte av batteri. Benytt same batteritype eller en tilsvarende type anbefalt av apparatfabrikanten. Brukte batterier kasseres I henhold til fabrikantens instruksjoner.

(Bulgarian) (български) ВНИМАНИЕ: Опасност от експлозия ако батерията бъде неправилно поставена. Поставете батерия от същия вид или еквивалентна батерия, която се препоръчва от производителя. Изхвърлете използваните батерии като спазвате указанията на производителя.

(Croatian) (Hrvatski) OPREZ: Opasnost od eksplozije ako se baterija zamijeni neprikladnom. Zamijenite je samo jednakom ili nadomjesnom vrstom prema preporuci proizvođača. Istrošene baterije zbrinite u skladu s uputama proizvođača.

(Estonian) (Eesti) ETTEVAATUST! Plahvatusoht, kui aku on valesti paigaldatud. Asendage ainult sama või tootja poolt soovitatud võrdväärse akuga. Hävitage kasutatud aku vastavalt tootja juhistele.

(Persian) (فارسی)

أخطار: در صورت عدم نصب و جا گذاری صحیح باتری، احتمال انفجار باتری وجود دارد. در صورت تعویض باتری، تنها از باتریهای پیشنهادی شرکت تولید کننده استفاده نمایید. از دور انداختن باتری خودداری کنید و بر طبق راهنمایی شرکت تولید کننده عمل نمایید.

(Arabic) (العربية)

تحذير: خطر، قد تتعرض البطارية للانفجار والتلف إذا تم استبدالها بنوع غير أصلي. أستبدل فقط بنفس أو نوع مكافئ أوصى به من قبل منتج الجهاز. تجاهل البطاريات المستعملة وفقا لإرشادات الشركة المصنعة.

WEEE Statement

(English) Under the European Union ("EU") Directive on Waste Electrical and Electronic Equipment, Directive 2002/96/EC, which takes effect on August 13, 2005, products of "electrical and electronic equipment" cannot be discarded as municipal waste anymore and manufacturers of covered electronic equipment will be obligated to take back such products at the end of their useful life.

(French) (Français) Au sujet de la directive européenne (EU) relative aux déchets des équipement électriques et électroniques, directive 2002/96/EC, prenant effet le 13 août 2005, que les produits électriques et électroniques ne peuvent être déposés dans les décharges ou tout simplement mis à la poubelle. Les fabricants de ces équipements seront obligés de récupérer certains produits en fin de vie.

(German) (Deutsch) Gemäß der Richtlinie 2002/96/EG über Elektro- und Elektronik-Altgeräte dürfen Elektro- und Elektronik-Altgeräte nicht mehr als kommunale Abfälle entsorgt werden, die sich auf 13.August, 2005 wirken. Und der Hersteller von bedeckt Elektronik-Altgeräte gesetzlich zur gebrachten Produkte am Ende seines Baruchbarkeitsdauer zurückzunehmen.

(Spanish) (Español) Bajo la directiva 2002/96/EC de la Unión Europea en materia de desechos y/o equipos electrónicos, con fecha de rigor desde el 13 de agosto de 2005, los productos clasificados como "eléctricos y equipos electrónicos" no pueden ser depositados en los contenedores habituales de su municipio, los fabricantes de equipos electrónicos, están obligados a hacerse cargo de dichos productos al termino de su período de vida.

(Italian) (Italiano) In base alla Direttiva dell'Unione Europea (EU) sullo Smaltimento dei Materiali Elettrici ed Elettronici, Direttiva 2002/96/EC in vigore dal 13 Agosto 2005, prodotti appartenenti alla categoria dei Materiali Elettrici ed Elettronici non possono più essere eliminati come rifiuti municipali: i produttori di detti materiali saranno obbligati a ritirare ogni prodotto alla fine del suo ciclo di vita.

(Russian) (Русский) В соответствии с директивой Европейского Союза (ЕС) по предотвращению загрязнения окружающей среды использованным электрическим и электронным оборудованием (директива WEEE 2002/96/EC), вступающей в силу 13 августа 2005 года, изделия, относящиеся к электрическому и электронному оборудованию, не могут рассматриваться как бытовой мусор, поэтому производители вышеперечисленного электронного оборудования обязаны принимать его для переработки по окончании срока службы.

(Turkish) (Türkçe) Avrupa Birliği (AB) Kararnamesi Elektrik ve Elektronik Malzeme Atığı, 2002/96/EC Kararnamesi altında 13 Ağustos 2005 tarihinden itibaren geçerli olmak üzere, elektrikli ve elektronik malzemeler diğer atıklar gibi çöpe atılamayacak ve bu elektonik cihazların üreticileri, cihazların kullanım süreleri bittikten sonra ürünleri geri toplamakla yükümlü olacaktır.

(Greek) (Ελληνικά) Σύμφωνα με την Οδηγία 2002/96/ΕΚ της Ευρωπαϊκής Ένωσης («ΕΕ») περί Απόρριψης Ηλεκτρικού και Ηλεκτρονικού Εξοπλισμού (WEEE), η οποία λαμβάνει ισχύ στις 13 Αυγούστου 2005, τα προϊόντα «ηλεκτρικού και ηλεκτρονικού εξοπλισμού» δεν είναι δυνατόν να απορριφθούν πλέον ως κοινά απορρίμματα και οι κατασκευαστές κεκαλυμμένου ηλεκτρονικού εξοπλισμού είναι υποχρεωμένοι να πάρουν πίσω αυτά τα προϊόντα στο τέλος της ωφέλιμης ζωής τους.

(Polish) (Polski) Zgodnie z Dyrektywą Unii Europejskiej ("UE") dotyczącą odpadów produktów elektrycznych i elektronicznych (Dyrektywa 2002/96/EC), która wchodzi w życie 13 sierpnia 2005, tzw. “produkty oraz wyposażenie elektryczne i elektroniczne " nie mogą być traktowane jako śmieci komunalne, tak więc producenci tych produktów będą zobowiązani do odbierania ich w momencie gdy produkt jest wycofywany z użycia.

(Hungarian) (Magyar) Az Európai Unió („EU") 2005. augusztus 13-án hatályba lépő, az elektromos és elektronikus berendezések hulladékairól szóló 2002/96/EK irányelve szerint az elektromos és elektronikus berendezések többé nem kezelhetőek lakossági hulladékként, és az ilyen elektronikus berendezések gyártói kötelessé válnak az ilyen termékek visszavételére azok hasznos élettartama végén.

(Czech) (Čeština) Podle směrnice Evropské unie ("EU") o likvidaci elektrických a elektronických výrobků 2002/96/EC platné od 13. srpna 2005 je zakázáno likvidovat "elektrické a elektronické výrobky" v běžném komunálním odpadu a výrobci elektronických výrobků, na které se tato směrnice vztahuje, budou povinni odebírat takové výrobky zpět po skončení jejich životnosti.

(Traditional Chinese) (繁體中文) 歐盟已制訂有關廢電機電子設備法令，亦即自 2005 年 8 月 13 日生效的 2002/96/EC，明文規定「電機電子設備產品」不可再以都市廢棄物處理，且所有相關電子設備製造商，均須在產品使用壽命結束後進行回收。

(Simplified Chinese) (简体中文) 欧盟已制订有关废电机电子设备法令，亦即自 2005 年 8 月 13 日生效的 2002/96/EC，明文规定「电机电子设备产品」不可再以都市废弃物处理，且所有相关电子设备制造商，均须在产品使用寿命结束后进行回收。

(Japanese) (日本語) 2005 年 8 月 13 日以降に EU 加盟国を流通する電気・電子製品には WEEE 指令によりゴミ箱に×印のリサイクルマークの表示が義務づけられており、廃棄物として捨てることの禁止とリサイクルが義務づけられています。

(Korean) (한국어) 2005 년 8 월 13 일자로 시행된 폐전기전자제품에 대한 유럽연합("EU") 지침, 지침 2002/96/EC 에 의거하여, "전기전자제품"은 일반 쓰레기로 폐기할 수 없으며 제품의 수명이 다하면 해당 전자제품의 제조업체가 이러한 제품을 회수할 책임이 있습니다.

(Vietnamese) (Tieng Viet) Theo Hướng dẫn của Liên minh Châu Âu ("EU") về Thiết bị điện & điện tử đã qua sử dụng, Hướng dẫn 2002/96/EC, vốn đã có hiệu lực vào ngày 13/8/2005, các sản phẩm thuộc "thiết bị điện và điện tử" sẽ không còn được vứt bỏ như là rác thải đô thị nữa và các nhà sản xuất thiết bị điện tử tuân thủ hướng dẫn sẽ phải thu hồi các sản phẩm này vào cuối vòng đời.

(Thai) (ไทย) ภายใต้ข้อกำหนดของสหภาพยุโรป ("EU") เกี่ยวกับของเสียจากอุปกรณ์ไฟฟ้า และอิเล็กทรอนิกส์ เลขที่ 2002/96/EC ซึ่งมีผลบังคับใช้ตั้งแต่วันที่ 13 สิงหาคม 2005 ผู้ใช้ไม่สามารถทิ้งผลิตภัณฑ์ที่เป็น "อุปกรณ์ไฟฟ้าและอิเล็กทรอนิกส์" ปะปนกับของเสียทั่วไปของชุมชนได้อีกต่อไป และผู้ผลิตอุปกรณ์อิเล็กทรอนิกส์ดังกล่าวจะถูกบังคับให้นำผลิตภัณฑ์ดังกล่าวกลับคืนเมื่อสิ้นสุดอายุการใช้งานของผลิตภัณฑ์

(Indonesian) (Bahasa Indonesia) Sesuai dengan Regulasi Uni Eropa ("UE") perihal WEEE (Limbah Peralatan Listrik dan Elektronik), Directive 2002/96/EC, yang berlaku sejak 13, 2005, produk "peralatan listrik dan elektronik" tidak lagi dapat dibuang sebagai sampah umum dan pabrik peralatan elektronik diwajibkan untuk mengambil kembali produk tersebut pada saat masa pakainya habis.

(Serbian) (Srpski) Po Direktivi Evropske unije ("EU") o odbačenoj ekektronskoj i električnoj opremi, Direktiva 2002/96/EC, koja stupa na snagu od 13. Avgusta 2005, proizvodi koji spadaju pod "elektronsku i električnu opremu" ne mogu više biti odbačeni kao običan otpad i proizvođači ove opreme biće prinuđeni da uzmu natrag ove proizvode na kraju njihovog uobičajenog veka trajanja.

(Netherlands) (Nederlands) De richtlijn van de Europese Unie (EU) met betrekking tot Vervuiling van Electrische en Electronische producten (2002/96/EC), die op 13 Augustus 2005 in zal gaan kunnen niet meer beschouwd worden als vervuiling. Fabrikanten van dit soort producten worden verplicht om producten retour te nemen aan het eind van hun levenscyclus..

(Romanian) (Română) În baza Directivei Uniunii Europene ("UE") privind Evacuarea Echipamentului Electric şi Electronic, Directiva 2002/96/EC, care intră în vigoare pe 13 august, 2005, produsele din categoria "echipament electric şi electronic" nu mai pot fi evacuate ca deşeuri municipale, iar fabricanţii echipamentului electronic vizat vor fi obligaţi să primească înapoi produsele respective la sfârşitul duratei lor de utilizare.

(Portuguese) (Português) De acordo com a Directiva 2002/96/EC de Resíduos de Equipamentos Eléctricos e Electrónicos da União Europeia (UE), efectiva desde o 13 de Agosto do ano 2005, os produtos de "equipamento eléctrico e electrónico" não podem ser descartados como resíduo municipal e os fabricantes do equipamento electrónico sujeitos a esta legislação estarão obligados a recolhar estes produtos ao finalizar sua vida útil.

(Swedish) (Svenska) Under Europeiska unionens ("EU") Weee-direktiv (Waste Electrical and Electronic Equipment), Direktiv 2002/96/EC, vilket trädde i kraft 13 augusti, 2005, kan inte produkter från "elektriska och elektroniska utrustningar" kastas i den vanliga hushållssoporna längre och tillverkare av inbyggd elektronisk utrustning kommer att tvingas att ta tillbaka sådan produkter när de är förbrukade.

(Finnish) (Suomi) Euroopan unionin (EU) 13.8.2005 voimaan tulleen sähkö- ja elektroniikkalaiteromua koskevan direktiivin 2002/96/EY mukaisesti "sähkö- ja elektroniikkalaitteita" ei saa enää hävittää talousjätteiden mukana. Direktiivin alaisen sähkö- tai elektroniikkalaitteen valmistajan on otettava laitteet takaisin niiden käyttöiän päättyessä.

(Slovak) (Slovenčina) Na základe smernice Európskej únie („EU“) o elektrických a elektronických zariadeniach číslo 2002/96/ES, ktorá vstúpila do platnosti 13. augusta 2005, výrobky, ktorými sú „elektrické a elektronické zariadenia" nesmú byť zneškodňované spolu s komunálnym odpadom a výrobcovia patričných elektronických zariadení sú povinní takéto výrobky na konci životnosti prevziať naspäť.

(Slovenian) (Slovenščina) Skladno z določili direktive Evropske unije ("EU") o odpadni električni in elektronski opremi, Direktiva 2002/96/ES, ki je veljavna od 13. avgusta, izdelkov "električne in elektronske opreme" ni dovoljeno odstranjevati kot običajne komunalne odpadke, proizvajalci zadevne elektronske opreme pa so zavezani, da tovrstne izdelke na koncu njihove življenjske dobe sprejmejo nazaj.

(Danish) (Dansk) I henhold til direktiv fra den europæiske union (EU) vedrørende elektrisk og elektronisk affald , Direktiv 2002/96/EC, som træder i kraft den 13. august 2005, må produkter som "elektrisk og elektronisk udstyr" ikke mere bortskaffes som kommunalt affald. Producenter af det pågældende, elektroniske udstyr vil være forpligtet til at tage disse produkter tilbage ved afslutningen på produkternes levetid.

(Norwegian) (Norsk) Under den europeiske unionens ("EU") direktiv om deponering av elektronisk og elektrisk utstyr, direktiv 2002/96/EC, som trer i effekt 13. august 2005, kan ikke produkter av "elektronisk og elektrisk ustyr" lenger deponeres som husholdningsavfall og fabrikantene av disse produktene er forpliktet å ta tilbake slike produkter ved slutten av produktets levetid.

(Bulgarian) (български) Според директивата на Европейския съюз относно отпадъците от електрическо и електронно оборудване, директива 2002/96/EC, важаща от 13 август, 2005 г., електрическо и електронно оборудване не може да се изхвърля заедно с битовите отпадъци и производителите на такова оборудване са задължени да приемат обратно съответните продукти в края на експлоатационния им период.

(Croatian) (Hrvatski) U okviru Direktive Europske Unije ("EU") o Otpadnim električnim i elektroničkim uređajima, Direktiva 2002/96/EC, koja je na snazi od 13. kolovoza 2005., "električni i elektronički uređaji" se ne smiju više bacati zajedno s kućnim otpadom i proizvođači su obvezni zbrinuti takve proizvode na kraju njihovog životnog vijeka.

(Estonian) (Eesti) Vastavalt Euroopa Liidu ("EL") direktiivile 2002/96/EÜ (elektri- ja elektroonikaseadmete jäätmete kohta), mis jõustus 13. augustil 2005, on keelatud kodumajapidamiste "elektri- ja elektroonikaseadmete" jäätmete hävitamine koos majapidamisjäätmetega, ja elektri- ja elektroonikaseadmete tootjad on kohustatud sellised tooted pärast nende kasutuselt kõrvaldamist tagasi võtma.

(Persian) (فارســـی)

اتحادیه اروپا) که از تاریخ 13 آگوست سال 2005 میلادی قابل اجراست ، کلیه شرکت های 2002/96/ECبر طبق قانون دفع زباله های الکتریکی و الکترونیکی (بند تولید کننده موظف به جمع آوری زباله محصولات خود پس از پایان دوره مصرف می باشند.

(Arabic) (العربية)

في إطار اتفاقية الإتحاد الأوربي ("الإتحاد الأوربي") التوجيه بشأن نفايات المعدات و الأجهزة الكهربائية والإلكترونية، توجيه 2002/96/EC للمجموعة الأوربية، الذى أصبح ساري المفعول في 13 أغسطس/آب، 2005، ان منتجات "أجهزة كهربائية وإلكترونية" لا يمكن التخلي عنها بوصفها نفايات، ومنتجو المعدات الالكترونية سيكون لزاما عليهم استرداد مثل هذه المنتجات في نهاية مدة صلاحيتها.

Optical Drive Device Notice

CAUTION: This appliance contains a laser system and is classified as a “CLASS 1 LASER PRODUCT.” To use this model properly, read the instruction manual carefully and keep this manual for your future reference. In case of any trouble with this model, please contact your nearest “AUTHORIZED service station.” To prevent direct exposure to the laser beam, do not try to disassemble the enclosure.

Trademarks

All trademarks are the properties of their respective owners.
SRS Premium Sound, SRS and the symbol are trademarks of SRS Labs, Inc.
THX and THX TruStudio Pro are trademarks of THX Ltd. which may be registered in some jurisdictions. All rights reserved.

Revision History

Version	Revision History	Date
1.0	First Released	06, 2010

CHAPTER 2

Introductions

Congratulations on becoming an user of this notebook, the finely designed notebook. This brand-new exquisite notebook will give you a delightful and professional experience in using notebook. We are proud to tell our users that this notebook is thoroughly tested and certified by our reputation for unsurpassed dependability and customer satisfaction.

Manual Map

This User's Manual provides instructions and illustrations on how to operate this notebook. It is recommended to read this manual carefully before using this notebook.

Chapter 1, Preface, gives users the basic safety information and caution that is interrelated to using this notebook. It is recommended to read these information or caution when using this notebook for the first time.

Chapter 2, Introductions, includes the descriptions of all the accessories of this notebook. It is recommended to check out that if you have all the accessories included when you open the packing box. If any of these accessories is damaged or missing, please contact the vendor where you purchased this notebook. Also, this chapter provides the specification of this notebook, and introduces the function buttons, quick launch buttons, connectors, LEDs and externals of this notebook.

Chapter 3, Getting Started, gives the basic operation instructions on using keyboard, touchpad, hard disk drive, and optical storage drive. Beside, the steps of installing and uninstalling the battery; and the procedures of connecting the various external devices, communication devices, and so on, are also provided to help users getting familiar with this notebook.

Chapter 4. BIOS Setup, provides information on BIOS Setup program and allows you to configure the system for optimum use.

Unpacking

First, unpack the shipping carton and check all items carefully. If any item contained is damaged or missing, please contact your local dealer immediately. Also, keep the box and packing materials in case you need to ship the unit in the future. The package should contain the following items:

	Notebook		Quick Start Manual
	High-capacity Li-ion battery		AC adapter and power cord
	Carry bag (optional)		
	All-in-one application disk, containing the full version of user's manual, drivers, utilities, and optional recovery function, etc.		

INFO

These accessories listed above may change without notice.

Specification

Physical Characteristic

Dimension	383 x 249.5 x 32.3 ~37 mm
Weight	2.4 kg (with 6-cell battery)

CPU

Processor Type	AMD® Champlain
L2 Cache	512KB to 2MB
HyperTransport Link	3.2GT/s or 3.6GT/s (optional)
Special Notification	The actual processor preinstalled in the notebook depends on the model you purchased. Please contact the local dealer for detailed information.

Core Chips

North Bridge	AMD® RS880M
South Bridge	AMD® SB820M
Special Notification	The actual core chips preinstalled in the notebook depends on the model you purchased. Please contact the local dealer for detailed information.

Memory

Technology	DDR3 1066 / 1333 MHz (optional)
Memory	DDR3 SO-DIMM X 2 slot
Maximum	4GB

Power

AC/DC Adapter	90W, 19V Input: 100~240V, 50~60Hz Output: 19V ⎓ 4.74A
Battery Type	6-cell
RTC Battery	Yes
Special Notification	The actual AC/DC Adapter and battery pack that come with the package may vary without notice.

Storage (Items listed here may vary depending on the model users purchased)

HDD form factor	2.5”, 9.5mm
Optical Drive Device	Super Multi / Blu-ray (optional)
Special Notification	The actual HDD and ODD preinstalled in the notebook depends on the model you purchased.

I/O Port

Monitor (VGA)	15 pin D-Sub x 1
USB	x 2 (USB version 2.0)
E-SATA / USB combo	x 1
Mic-in/ Line-in	x 1
Headphone-out/ S/PDIF-out	x 1
RJ45	x 1
HDMI	x 1
Card Reader	x 1 (XD/ SD/ SDHC/ SDXC/ MMC/ MS/ MS Pro) The supported memory cards may vary without notice.

Communication Port (Items listed here may vary without notice)

LAN	Giga LAN (optional)
Wireless LAN	802.11b/g/n (optional)
Bluetooth	Optionally supported

Audio

Internal Speaker	2 speakers
Sound Volume	Adjust K/B hot-key & SW

Video

Graphics	Discrete/ UMA (optional)
LCD Resolution	1366 x 768
CRT Output	Supported
HDMI Output	Supported

Display

LCD Type	15.6” 16:9 HD
Brightness	Brightness controlled by K/B hot-keys

WebCam

HD CMOS camera	Supported

Software & BIOS

USB Flash Boot	Yes, USB floppy boot up DOS only
BIOS	Fast Boot Support --- Yes

Others

Kensington Lock Hole	x 1
Compliance	WHQL

Product Overview

This section provides the description of basic aspects of the notebook. It will help you to know more about the appearance of this notebook before using it. Please be aware that the notebook shown in this section may vary from the actual one that users purchased.

Top-open View

The figure of top-open view and description shown below will lead you to browse the main operating area of your notebook.



1. Internal Microphone
2. Webcam / Webcam LED
3. Quick Launch Buttons
4. Touchpad Switch
5. Touchpad
6. Keyboard / Quick Launch [Fn] Buttons

INFO

The figures show here are for reference only.

1. **Internal Microphone**

   The built-in speaker and array microphone increase the accuracy of speech recognition feature, allow inputs to be combined into a single, higher-quality source.

2. **Webcam/ Webcam LED**

   - This built-in Webcam can be used for picture taking, video recoding or conference, and any other interactive applications.
   - Webcam LED indicator, next to the webcam, glows white when webcam function is activated; LED goes out when this function is turned off.

3. **Quick Launch Buttons**

   Press the quick launch button to activate the specific applications or tools. With the help of these buttons, users will be able to do work more efficiently.

Volume Down/ Volume Up	◆ Press the **Volume Down** or **Volume Up** button to decrease or increase the sound volume. ◆ Read the icon on behalf of the Sound Level Status appearing on the display to learn the function status.
Cinema Pro	◆ Press this button to activate the **Cinema Pro** function which enhances the playback quality from your display device and sound system. Press again to turn this function off. ◆ Read the icon on behalf of the **Cinema Pro** function appearing on the display to learn the function status.

Wireless LAN (optional)	◆ Press this button to launch the **Wireless LAN** function.
P1 **GPU Boost**	◆ Press this button to launch the **GPU Boost** application. ◆ Glowing amber indicates in High-performance GPU, while off in Power-saving GPU mode. ◆ GPU Boost Function allows users to choose between using the discrete and the internal graphic card depending on the tasks users are currently performing. ◆ Refer to the Power Management section in chapter 3 of this manual for the detailed information of this GPU Boost Function.
	Power Button ◆ Press the power button to turn the notebook power ON and OFF. ◆ Press the power button to awake the notebook from the sleep state. **Power/ Power Saving function LED** ◆ Glowing blue when the notebook power is turned on. ◆ LED goes off when this function is turned off. ◆ The Power and Sleep State LED blinks blue at the same time, when the system is currently in the Sleep state.

4. **Touchpad Switch**

   This switch can be used to enable or disable the touchpad. There is an optional LED on the button, glows when the touchpad is disabled.

5. **Touchpad**

   This is a pointing device of the notebook.

6. **Keyboard**

   The built-in keyboard provides all the functions of a full-sized keyboard.

   Quick Launch [Fn] Buttons

   Use the **[Fn]** buttons on the keyboard to activate the specific applications or tools.

   With the help of these quick launch buttons, users will be able to do work more efficiently.

   The descriptions mentioned here are for reference only, and may be optional supported depending on the models users purchased.

 **Smart Pad**	◆ Press and hold the **Fn** button, and then press the **F3** button repeatedly to enable or disable the **Smart Pad** function recurrently. ◆ There is an optional LED on the button, glows when the touchpad is disabled.
 **GPU Boost**	◆ Press and hold the **Fn** button, and then press the **F4** button to launch the **GPU Boost** application. ◆ Refer to the Power Management section in chapter 3 of this manual for the detailed information of this GPU Boost Function.

 **ECO Engine** **(Power Saving)**	◆ Press and hold the **Fn** button, and then press the **F5** button repeatedly to switch among various power saving modes provided by **ECO Engine**, or to turn this function off recurrently. ◆ Refer to the Power Management section in chapter 3 of this manual for the detailed information of this ECO Engine, Power Saving Function. ◆ Note that ECO Engine is an optional function.
 **Webcam**	◆ Press and hold the **Fn** button, and then press the **F6** button to turn the **Webcam** function on. Press again to turn it off.
 **WLAN (WiFi)** **(optional)**	◆ Press and hold the **Fn** button, and then press the **F8** button to turn the **Wireless LAN (WiFi)** function on. Press again to turn it off.
 **Bluetooth** **(optional)**	◆ Press and hold the **Fn** button, and then press the **F9** button to turn the **Bluetooth** function on. Press again to turn it off.



3G
(optional)

- Press and hold the **Fn** button, and then press the **F10** button to turn the **3G** function on. Press again to turn it off.
- This **3G** function is optional supported depending on the model users purchased. This function button will not be available when the 3G function is not supported.

Front View



1. Status LED
2. Card Reader

1. Status LED

	Hard Disk/ Optical Drive Device In-use: Blinking blue when the system is accessing the hard disk drive or the optical drive device.
 Bluetooth	**Bluetooth** ◆ Bluetooth LED indicator glows blue when Bluetooth function is enabled. ◆ **Warning:** For flight safety consideration, make sure this LED indicator goes out when you are in flight. ◆ **Note:** The Bluetooth Function may be optionally supported depending on the model users purchased. ◆ Contact the local distributor for further information if necessary.

WLAN(WiFi)	**Wireless LAN (WiFi) (optional)** ◆ Wireless LAN LED indicator glows blue when Wireless LAN (WiFi) function is enabled. ◆ LED indicator goes out when this function is disabled. ◆ **Warning:** For flight safety consideration, make sure this LED indicator goes out when you are in flight. ◆ Contact the local distributor for further information if necessary.
	Battery: ◆ Glowing blue when the battery is being charged. ◆ Glowing amber when the battery is in low battery status. ◆ Blinking amber if the battery fails and it is recommended to replace a new battery. Consult the local dealer for purchasing an equivalent type of battery recommended by the manufacturer. ◆ Battery LED goes out when it is fully charged or when the AC/DC adapter is disconnected.
	Caps Lock: Glowing blue when the Caps Lock function is activated.
	Num Lock: Glowing blue when the Num Lock function is activated.

Sleep State:

- Blinking blue when the system is in Sleep state.
- Glowing blue when the system is activated.
- LED goes out when the system is turned off.

2. **Card Reader**

   The built-in card reader may support various types of memory card, such as MMC (Multi-Media Card), XD (eXtreme Digital), SD (Secure Digital), SDHC (SD High Capacity), SDXC (eXtended Capacity), MS (Memory Stick) or MS Pro (Memory Stick Pro) cards. Contact the local dealer for further and correct information and be noted that **the supported memory cards may vary without notice.**

Right Side View



1. Optical Drive Device
2. E-SATA / USB Combo Port
3. VGA Port
4. RJ-45 Connector

1. Optical Drive Device

This notebook is equipped with an optical drive device. The actual device preinstalled in the notebook depends on the model you purchased.

2. E-SATA (External Serial ATA) / USB Combo Port

The E-SATA Connector allows you to connect an external Serial ATA device. Users can now utilize shielded cable outside the notebook to take advantage of the benefits the SATA interface brings to storage. This connector may also work as an USB Port.

3. VGA Port

The 15-pin D-Sub VGA port allows you to connect an external monitor or other standard VGA-compatible device (such as a projector) for a great view of the computer display.

4. RJ-45 Connector

The Ethernet connector is used to connect a LAN cable for network connection.

Left Side View



1. Kensington Lock Hole
2. Power Connector
3. Ventilator
4. HDMI Connector
5. USB Port
6. Audio Port Connectors

1. Kensington Lock Hole

This notebook provides a Kensington Lock hole, which allows users to secure the notebook in place with a key or some mechanical PIN device and attached through a rubberised metal cable. The end of the cable has a small loop which allows the whole cable to be looped around a permanent object, such as a heavy table or other similar equipment, thus securing the notebook in place.

2. Power Connector

To connect the AC/DC adapter and supply power for the notebook.

3. Ventilator

The ventilator is designed to cool the system. DO NOT block the ventilator for air circulation.

4. HDMI Connector

HDMI (High Definition Multimedia Interface) is a new interface standard for PCs, displays and consumer electronics devices that supports standard, enhanced and high-definition video, plus multi-channel digital audio on a single cable.

5. USB Port

The USB 2.0 port allows you to connect USB-interface peripheral devices, such as the mouse, keyboard, modem, portable hard disk module, printer and more.

6. Audio Port Connectors

Make high quality sound blaster with stereo system and Hi-Fi function supported. Connect your speakers to the proper connectors as shown below.

Mic In/Line In: Used for an external microphone.

Headphone out/ SPDIF-out: Used for speakers or headphones. The S/PDIF connector is also provided for digital audio transmission to external speakers through an optical fiber cable.

Rear Side View



1. Battery Pack

1. Battery Pack

This notebook will be powered by the battery pack when the AC adapter is disconnected.

Bottom Side View



1. Battery Lock/ Unlock Button
2. Battery Pack
3. Battery Release Button
4. Ventilator
5. Stereo Speaker

1. Battery Lock/ Unlock Button

Battery cannot be moved when the button is positioned on lock status. Once the button is slid to unlock position, the battery is removable.

2. Battery Pack

This notebook will be powered by the battery pack when the AC adapter is disconnected.

3. **Battery Release Button**

   It is a bounce-back device as a preparation for releasing the battery pack. Slide it with one hand and pull the battery pack carefully with the other.

4. **Ventilator**

   The ventilator is designed to cool the system. DO NOT block the ventilator for air circulation.

5. **Stereo Speaker**

   Give high quality sound blaster with stereo system and Hi-Fi function supported.

CHAPTER 3

Getting Started

Power Management

Connecting the AC power

It is strongly recommended to connect the AC/DC adapter to the notebook and use the AC power while using this notebook for the first time. When the AC power is connected, recharging the battery will start immediately.

Note that the AC/DC adapter included in the package is approved for your notebook; using other adapter model may damage either the notebook or other devices attached to it.

Do not cover the AC/DC adapter since it may produce a certain heat while in use. Always be aware of heat coming from the AC/DC adapter in use.

Connecting the AC Power

1. Unpack the package to find the AC/DC adapter and power cord.
2. Attach the power cord to the connector of the AC/DC adapter.
3. Plug the DC end of the adapter to the notebook, and the male end of the power cord to the electrical outlet.

Disconnecting the AC Power

When you disconnect the AC/DC adapter, you should:

4. Unplug the power cord from the electrical outlet first.
5. Unplug the connector from the notebook.
6. Disconnect the power cord and the connector of AC/DC adapter.
7. When unplugging the power cord, always hold the connector part of the cord. Never pull the cord directly!



Using the Battery Power

This notebook is equipped with a high-capacity Li-ion battery pack. The rechargeable Li-ion battery pack is an internal power source of the notebook.

Be aware of that this battery pack may be damaged if users try to disassemble the battery pack on their own. Also, note that the limited warranty to the battery pack may also lose its efficacy when this battery pack is disassembled not by an authorized machinist.

To prevent explosion caused by improper battery replacement, use the same or equivalent type of battery recommended by the manufacturer only.

Always keep the battery which is not in use in a safe place.

Please follow your local laws and regulations to recycle the unused battery pack.

Installing the Battery Pack

To insert the battery pack, following the steps below:

1. Locate the steady gutter of the battery pack, and the battery bolt on the battery tray as shown right.



2. Align the steady gutter and battery bolt with correct orientation and make sure they are joined properly.



3. Overturn the battery pack with the direction shown right.



4. Press down the battery pack to fasten the battery pack in the battery tray.

5. Press the lock/unlock button to the Lock position to make sure the battery pack is securely fastened.



INFO

The figures show here are for reference only.

Releasing the Battery Pack

To release the battery pack, following the steps below:

1. Make sure the notebook is turned off, and the AC power is disconnected.
2. Press the lock/unlock button to the unlocked position.
3. Locate the battery release button on the bottom side.
4. Push and hold the release button to the battery releasing direction as shown on the bottom side.
5. Dig the edge of battery pack out of the battery tray with your finger tip. Be careful with your finger while trying to take out the battery pack.
6. Stand the battery pack upright first, and then pull the battery pack out. Do not use force here.



Battery Safety Tips

Replacing or handling the battery incorrectly may present a risk of fire or explosion, which could cause serious injury.

- Only replace the main battery pack with the same or equivalent type of battery.
- Do not disassemble, short-circuit or incinerate batteries or store them to temperatures above +60° C (+140° F).
- Do not temper with batteries. Keep away from the reach of children.
- Do not use rusty or damaged batteries.
- Dispose of batteries according to local regulations. Check with your local solid waste officials for details about recycling options or for proper disposal in your area.

Conserving Battery Power

Efficient battery power is critical to maintain a normal operation. If the battery power is not managed well, the saved data and customized settings may be lost.

To optimize battery life and avoid a sudden power loss, read the tips below:

- Suspend system operation if the system will be idle for a while or shorten the suspend timer's time period.
- Turn off the system if you won't be using it for a period of time.
- Disable unnecessary settings or remove idle peripherals.
- Connect an AC/DC adapter to the system whenever possible.

Charging the Battery Pack

The battery pack can be recharged while it is installed in the notebook. Please pay attention to the following tips before recharging the battery:

- If a charged battery pack is not available, save your work and close all running programs and shut down the system or Save-to-Disk.
- Plug in an external AC/DC adapter.
- You can use the system, suspend system operation or shut down and turn off the system without interrupting the charging process.
- The battery pack uses Lithium-ion battery cells that have no “memory effect.” It is unnecessary to discharge the battery before recharging. However, to optimize the life of battery, we suggest that consuming the battery power completely once a month is necessary.
- If you do not use the notebook for a long time, it is suggested to remove the battery pack from your notebook. This may be helpful to extend your battery life.
- The actual charging time will be determined by the applications in use.

ECO Engine -- Power Saving Function (Optionally supported)

Enabling the ECO Engine

ECO Engine, the outstanding and unique power saving function, provides various power saving modes – **Gaming mode**, **Movie mode**, **Presentation mode**, **Office mode**, and **Turbo Battery mode**, to extend the battery running time while performing different tasks with this notebook.

Read the instructions bellow to activate the ECO Engine power saving function:

1. Press and hold the **Fn** button.
2. Press the **F5** button repeatedly to switch among the different modes of ECO Engine, or to turn this ECO Engine off recurrently.
3. To learn which power saving mode is activated presently, read the icon on behalf of each mode appearing on the display when selected.

Gaming Mode

Gaming Mode

Select this mode while performing game applications.

Movie Mode

Movie Mode

Select this mode while playing multimedia applications

Presentation Mode

Presentation Mode

Select this mode while performing presentation applications.

Office Mode

Office Mode

Select this mode while dealing with office documentation tasks.

Turbo Battery Mode

Turbo Battery Mode

Select this mode to maximize the battery running time.

ECO Off

Selected to disable ECO Engine.

GPU Boost Function (Optionally supported)

GPU Boost Function allows users to choose between using the discrete and the internal graphic card depending on the tasks users are currently performing. With this function, users can easily and quickly select either to maximizing the graphic performance or extending the battery running time.

1. Select a proper GPU mode by pressing the **P1** or **Fn+F4** button.

2. Bringing up the ATI PowerXpress™ dialogue by right clicking the mouse on the desktop, and select [**Configure ATI PowerXpress(TM)**].

3. In the ATI PowerXpress™ dialogue, users can read the status of graphics mode and also be able to choose a proper graphics processing unit here.

4. For more settings on graphics, please select [**Graphics Properties**] to bring up the sub-dialogue of the graphics.

5. It is recommended to close all programs when switching graphics mode. Screen will blink while switching modes, which is a normal behavior.



INFO

The figures show here are for reference only.

Power Management in Windows OS

Power management of personal computers (PCs) and monitors has the potential to save significant amounts of electricity as well as deliver environmental benefits. To be energy efficient, turn off your display or set your PC to Sleep/ Hibernate mode after a period of user inactivity.

Follow the instructions below to adjust the power management settings in Windows OS:

1. "**Power Options**" selection in Windows OS allows you to control the power management features of your display, hard drive, and battery. Go to the **Start** menu and click on the **Control Panel**. Click on the **System and Security**.
2. Then click on the "Power Options".
3. Then "**Select a power plan**" that meets your personal needs
4. The "Shut down" Computer menu will present various relative options as following.
5. The computer should be able to wake up from power saving mode in response to a command from any of following:
   - the power button,
   - the mouse,
   - the keyboard.


1
System and Security
Review your computer's status
Back up your computer
Find and fix problems
2
Power Options
Require a password when the computer wakes
Change what the power buttons do
Change when the computer sleeps
3
Select a power plan
Power plans can help you maximize your computer's performance or conserve energy. Make a plan active by selecting it, or choose a plan and customize it by changing its power settings. Tell me more about power plans
Preferred plans
Balanced (recommended)
Change plan settings
Automatically balances performance with energy consumption on capable hardware.
Power saver
Change plan settings
Saves energy by reducing your computer's performance where possible.
Show additional plans
4
Switch User
Log Off
Lock
Restart
Sleep
Hibernate
Shut down

Energy Saving Tips

- Activate the ECO power saving function to manage the computer's energy consumption.
- Turn off the monitor after a period of user inactivity.
- Utilize the **Fn** and **F12** sleep mode keys to turn into power saving mode.
- Tune the settings in Power Options under Windows OS to optimize the computer's power management.
- Always disconnect the AC power cord or uninstall the battery pack or switch off the wall socket if the computer would be left unused for a certain time to achieve zero energy consumption.

Basic Operations

If you are a beginner to the notebook, please read the following instructions to assure your own safety, and make yourself comfortable during the operations.

Safety and Comfort Tips

The notebook is a portable platform that allows you to work anywhere. However, choosing a good workspace is important if you have to work with your notebook for a long period of time.

- Your work area should have enough illumination.
- Choose the proper desk and chair and adjust their height to fit your posture when operating.
- When sitting on the chair, adjust the chair's back (if available) to support your back comfortably.
- Place you feet flat and naturally on the floor, so that your knees and elbows have the proper position (about 90-degree) when operating.
- Put your hands on the desk naturally to support your wrists.
- Adjust the angle/position of the LCD panel to have an optimal view.
- Avoid using your notebook in the space where may cause you discomfort (such as on the bed).
- The notebook is an electrical device, please treat it with great care to avoid personal injury

1. Keep your hands and feet with optimal comfort.
2. Adjust the angle and position of LCD panel.
3. Adjust the desk's height.
4. Sit straight and keep a good posture.
5. Adjust the chair's height.

Having a Good Work Habit

Have a good work habit is important if you have to work with your notebook for long periods of time; otherwise, it may cause discomfort or injury to you. Please keep the following tips in mind when operating.

- Change your posture frequently.
- Stretch and exercise you body regularly.
- Remember to take a break after working for a period of time.

Knowing the Keyboard

This notebook provides a full-functioned keyboard. This keyboard can be divided into four categories: **Typewriter keys**, **Cursor keys**, **Numeric keys** and **Function keys**.

Typewriter keys

Numeric keys

Cursor keys / Function keys

INFO

The keyboard shown here may vary from the actual one, depending on which county users purchase the notebook.

Typewriter Keys

In addition to providing the major function of the keyboard, these typewrite keys also provide several keys for special purposes, such as [**Ctrl**,] [**Alt**,] and [**Esc**] key.

When the lock keys are pressed, the corresponding LEDs will light up to indicate their status:

- **Num Lock:** Press the Num Lock key to toggle the Num Lock on and off. When this function is activated, you can use the numeric keys that are embedded in the typewriter keys.
- **Caps Lock:** Press the Caps Lock key to toggle the Caps Lock on and off. When this function is activated, the letters you type are kept in uppercase.
- **Scroll Lock:** Press the Scroll Lock key to toggle the Scroll Lock on and off. This function is defined by individual programs, and is usually used under DOS.

Numeric Keys

Find the numeric keys among the keyboard, and activate the Num Lock function to use these numeric keys to enter numbers and calculations.

Cursor Keys

The four cursor (arrow) keys and [**Home**], [**PgUp**], [**PgDn**], [**End**] keys are used to control the cursor movement.

	Move the cursor left for one space.
	Move the cursor right for one space.
	Move the cursor up for one line.
	Move the cursor down for one line.
	Move to the previous page.
	Move to the next page.
	Move to the beginning of the line (or document).
	Move to the end of the line (or document).

The Backspace key, **[Ins]** and **[Del]** keys at upper right corner are used for editing purpose.

Insert	This key is used to switch the typing mode between “insert” and “overtype” modes.
Delete	Press this key to delete one character to the right of the cursor and move the following text left for one space.
Backspace	Press this key to delete one character to the left of the cursor and move the following text left for one space.

Function Keys

- **Windows Keys**

  You can find the Windows Logo key ( ) and one Application Logo key ( ) on the keyboard, which are used to perform Windows-specific functions, such as opening the Start menu and launching the shortcut menu. For more information of the two keys, please refer to your Windows manual or online help.

- **[Fn] Key**

Fn + F2	Switch the display output mode between the LCD, external monitor and both.

	Enable or disable the touchpad function.
	Decrease the LCD brightness.
	Increase the LCD brightness.
	Decrease the built-in speaker's volume.
	Increase the built-in speaker's volume.
	Disable the computer's audio function.
	Force the computer into sleep state (depending on the system configuration).

■ Quick Launch [Fn] Buttons

Use the [Fn] buttons on the keyboard to activate the specific applications or tools.
With the help of these quick launch buttons, users will be able to do work more efficiently.



Smart Pad

- Press and hold the **Fn** button, and then press the **F3** button repeatedly to enable or disable the **Smart Pad** function recurrently.
- There is an optional LED on the button, glows when the touchpad is disabled.



GPU Boost

- Press and hold the **Fn** button, and then press the **F4** button to launch the **GPU Boost** application.
- Refer to the Power Management section in chapter 3 of this manual for the detailed information of this GPU Boost Function.



ECO Engine

(Power Saving)

- Press and hold the **Fn** button, and then press the **F5** button repeatedly to switch among various power saving modes provided by **ECO Engine**, or to turn this function off recurrently.
- Refer to the Power Management section in chapter 3 of this manual for the detailed information of this ECO Engine, Power Saving Function.
- Note that ECO Engine is an optional function.

 **Webcam**	◆ Press and hold the **Fn** button, and then press the **F6** button to turn the **Webcam** function on. Press again to turn it off.
 **WLAN (WiFi) (optional)**	◆ Press and hold the **Fn** button, and then press the **F8** button to turn the **Wireless LAN (WiFi)** function on. Press again to turn it off.
 **Bluetooth (optional)**	◆ Press and hold the **Fn** button, and then press the **F9** button to turn the **Bluetooth** function on. Press again to turn it off.
 **3G (optional)**	◆ Press and hold the **Fn** button, and then press the **F10** button to turn the **3G** function on. Press again to turn it off. ◆ This **3G** function is optional supported depending on the model users purchased. This function button will not be available when the 3G function is not supported.

Knowing the Smart Pad

The Smart Pad integrated in your notebook allows users to perform various actions with multi-finger taps and gestures while operating the notebook, and is capable to detect the changes of the multi-finger movement performed by users precisely. This significant Smart Pad will surely bring users not only an efficient but also an enjoyable experience of using the notebook.

1. **Cursor Movement Area**
   This pressure-sensitive area of the touchpad, allows you to place your finger on and control the cursor on the screen by moving one of your finger.

2. **Right / Left Buttons**
   Acts as the mouse's right/ left button.



INFO

The touchpad figures shown here are for reference only, and may be different from the notebook that users purchased.

Enabling the Smart Pad



Smart Pad

- Press and hold the **Fn** button, and then press the **F3** button repeatedly to enable or disable the **Smart Pad** function recurrently.
- There is an optional LED on the button, glows when the touchpad is disabled.

Brief Usages to the Smart Pad

For the further information on how to use the Smart Pad function specifically, please refer to the instructions of Smart Pad by double clicking the Smart Pad icon ( ) on the lower right side of the screen.

Gestures	Actions	Functions
	◆ Taping the touchpad once with one finger.	◆ Single clicking the **Left** button of the mouse.
	◆ Double taping the touchpad with one finger.	◆ Double clicking the **Left** button of the mouse.
	◆ Touch the touchpad with single finger and move around your finger on the touchpad.	◆ Cursor moving.
	◆ Move the cursor to a particular object with single finger. ◆ Select the object by tap the touchpad once ◆ Double tap the selected object with single finger, and remain your finger on the touchpad. ◆ Move your finger to drag the selected object	◆ Dragging an object.

Gestures	Actions	Functions
	◆ Touch the touchpad with two fingers and remain the fingers on the touchpad. ◆ Move the two fingers on the touchpad vertically.	◆ Scrolling a page vertically.
	◆ Touch the touchpad with two fingers and remain both fingers on the touchpad. ◆ Move the two fingers on the touchpad horizontally.	◆ Scrolling a page horizontally.
	◆ Touch the touchpad with two fingers and remain both fingers on the touchpad. ◆ Move two fingers to close each other to Zoom In the screen. ◆ Move two fingers away each other to Zoom Out the screen.	◆ Zoom In/ Out the screen.

Gestures	Actions	Functions
 	◆ Touch the touchpad with three fingers and remain it on the touchpad. ◆ Double tapping the touchpad with one finger to enable the Magnifying Glass function. ◆ To control the magnifying glass, touch the touchpad with single finger and move around your finger on the touchpad. ◆ To disable this function, simply tapping the touchpad once with single finger.	◆ Enabling or Disabling the Magnifying Glass function. ◆ Using the Magnifying Glass function.
	◆ Touch the touchpad with three fingers and remain the fingers on the touchpad. ◆ Move the three fingers to the Left on the touchpad to Page-up the screen.	◆ Page Up
	◆ Touch the touchpad with three fingers and remain the fingers on the touchpad. ◆ Move the three fingers to the Right on the touchpad to Page-down the screen.	◆ Page Down

Gestures	Actions	Functions
	◆ Touch the touchpad with three fingers and remain the fingers on the touchpad. ◆ Move the three fingers to the upper side of the touchpad to browse “Computer.”	◆ Browse the directory of “Computer”
	◆ Touch the touchpad with three fingers and remain the fingers on the touchpad. ◆ Move the three fingers to the lower side of the touchpad and remain the fingers on the touchpad still. ◆ Move a finger to the right or to the left to select the expected window. ◆ All fingers leave from the touchpad and the selected window will be popped up.	◆ Switching between all the windows that have been activated currently.

Gestures	Actions	Functions
 	◆ Touch the touchpad with two fingers and remain both fingers on the touchpad. ◆ Move a finger clockwise while another remains still to rotate a selected object clockwise. Refer to the first gesture. ◆ Move a finger counterclockwise while another remains still to rotate a selected object counterclockwise. Refer to the second gesture.	◆ Rotating a selected object clockwise or counterclockwise.
	◆ Taping the touchpad once with two fingers.	◆ May be defined by Users.
	◆ Taping the touchpad once with three fingers.	◆ May be defined by Users.
	◆ Place and remain a finger on the touchpad for a while. ◆ Reading and measuring the dimension of the finger by the Smart Pad.	◆ Avoiding improper gesture reading

About Hard Disk Drive

Your notebook is equipped with a 2.5-inch hard disk drive. The hard disk drive is a storage device with much higher speed and larger capacity than other storage devices, such as the floppy disk drive and optical storage device. Therefore, it is usually used to install the operating system and software applications.

To avoid unexpected data loss in your system, please backup your critical files regularly.

Do not turn off the notebook when the hard disk In-use LED is on.

Do not remove or install the hard disk drive when the notebook is turned on. The replacement of hard disk drive should be done by an authorized retailer or service representative.

Using the Optical Drive Device

Your notebook is equipped with an optical drive device. The actual device preinstalled in your notebook depends on the model you purchased.

- **Super Multi:** Works as a multi-functional DVD Dual Drive and a DVD RAM Drive.

- **Blu-ray:** It is a high-capacity optical disc that holds 4.5 hours of high-definition video (HD) on a single-sided, single-layer 25GB disk. Blu-ray supports the more advanced H.264 and VC-1 video encoding algorithms (codecs) as well as MPEG-2, which is used for DVD. It also supports 1080p, the highest HDTV resolution.

Inserting the Disk

The following instructions describe the general procedure when operating the optical storage device:

1. Confirm that the notebook is turned on.
2. Press the eject button on the panel and the disk tray will slide out partially.
3. Gently pull the tray out until fully extended.
4. Place your disk in the tray with its label facing up. Slightly press the center of the disk to secure it into place.
5. Push the tray back into the drive.



INFO

1. ***Confirm that the disk is placed correctly and securely in the tray before closing the tray.***
2. ***Do not leave the disk tray open.***

Removing the Disk

Follow the instructions below to remove the disk
that is placed in the optical storage device:

6. Press the eject button on the drive's panel and the disk tray will slide out partially.

7. Gently pull the tray out until fully extended.

8. Hold the disk by its edge with your fingers and lift it up from the tray.

9. Push the tray back into the drive.



Connecting the External Devices

The I/O (input/output) ports on the notebook allow you to connect peripheral devices. All devices listed here are for reference only.

Connecting the Peripheral Devices

Connecting the USB devices

This notebook provides USB ports for connecting various USB devices, such as mouse, keyboard, digital camera, webcam, printer, and external optical storage device, etc. To connect these devices, install the drivers for each device first if necessary, and then connect the device to the notebook. This notebook is capable to auto detect the USB devices installed, and if there is no detection of the devices, please manually enable the USB devices by going to **Start Menu** / **Control Panel** / **Add Hardware** to add the new device.



INFO

The devices shown in the reference figures here may be different from the devices users have.

Connecting the External Display Devices

This notebook provides a VGA port for connecting a larger display with higher resolution. The 15-pin-D-sub VGA port allows users to connect an external monitor or other standard VGA-compatible device (such as a projector) for a great view of the notebook display.



This notebook provides a HDMI port for connecting a larger display with higher resolution. HDMI (High Definition Multimedia Interface) is a new interface standard for PCs, displays and consumer electronics devices that supports standard, enhanced and high-definition video, plus multi-channel digital audio on a single cable.



To connect the external display, make sure the notebook and the external display are both powered off, and then connect the display to the notebook.

Once the display is connected to the notebook, power on the notebook and the external display should respond by default. If not, you can switch the display mode by pressing [**Fn**]+[**F2**]. Alternately, you can change the display mode by configuring the settings in Display Properties of Windows operating system.

Connecting the External SATA Hard Disk device

The E-SATA Connector allows you to connect an external Serial ATA hard disk device. Users can now utilize shielded cable outside the notebook to take advantage of the benefits the SATA interface brings to storage.

The E-SATA standard interface supports “plug-and-play” technology, so that you can connect and remove the E-SATA devices without turning off the notebook.

To connect the E-SATA hard disk device, simply connect the cable of the device to the E-SATA Connector of your notebook.



Connecting the Communication Devices

Using the LAN

The RJ-45 connector of the notebook allows you to connect the LAN (local area network) devices, such as a hub, switch and gateway, to build a network connection.



For more instructions or detailed steps on connecting to the LAN, please ask your MIS staff or network manager for help.

Using Wireless LAN Connection (optionally supported)

This notebook is equipped with wireless LAN module which allows users to perform fast data transmission with the standard IEEE 802.11 for wireless LAN. This gives users the mobility to move around within a broad coverage area and still be connected to the network.

By using the 64-bit/128-bit Wired Equivalent Privacy (WEP) encryption technology and Wi-Fi Protected Access feature, the optional built-in wirelesses LAN is capable to achieve a more efficient and a more secure solution to the wireless communication.

For more instructions or detailed steps on connecting to the Wireless LAN, please ask your MIS staff or network manager for help.



Using Bluetooth Connection (optionally supported)

This notebook is equipped with Bluetooth module which allows users to connect various Bluetooth-enabled devices to the notebook. Bluetooth provides a way to connect and exchange information between devices such as mobile phones, personal computers, printers, GPS receivers, PDAs, digital cameras, and video game consoles through a secure, globally unlicensed Industrial, Scientific and Medical (ISM) 2.4 GHz short-range radio frequency bandwidth.

For more instructions or detailed steps on using the Bluetooth function, please ask your MIS staff or network manager for help.



Components Replacement and Upgrade

Please be noticed that the memory, hard disk drive, wireless LAN / Bluetooth module and battery pack preinstalled in the product users purchased may be upgradable or replaceable by user's request depending on the models users purchased.



This notebook is equipped with a high-capacity Li-ion battery pack, and the battery pack is replaceable by users.
To replace the battery pack, please refer to the section of Using the Battery Power for details.

This notebook is equipped with a wireless LAN/ Bluetooth module, and the module may be upgradable and replaceable by authorized dealer or service center.



This notebook is equipped with a hard disk drive, and this storage device may be upgradable and replaceable by the authorized dealer or service center.

Additional memory module may be installed, by the authorized dealer or service center, to increase the performance of this notebook, depending on the specification limitation.

This notebook is equipped with an optical drive device, and this storage device may be upgradable and replaceable by the authorized dealer or service center.

To learn more about upgrade limitation, please refer to the specification in the User's Manual provided. For any further information about the product users purchased, please contact the local dealer.

Do not attempt to upgrade or replace any component of the product, if you are not an authorized dealer or service center, since it may cause the warranty void. It is strongly recommended to contact the authorized dealer or service center for any upgrade or replace service.

CHAPTER 4

BIOS Setup

About BIOS Setup

When to Use BIOS Setup?

You may need to run the BIOS Setup when:

- An error message appears on the screen during the system booting up and is requested to run SETUP.
- You want to change the default settings for customized features.
- You want to reload the default BIOS settings.

How to Run BIOS Setup?

To run the BIOS Setup Utility, turn on the notebook and press the [Del] key during the POST procedure.
If the message disappears before you respond and you still wish to enter Setup, either restart the system by turning it OFF and ON, or simultaneously pressing [Ctrl]+[Alt]+[Delete] keys to restart.

Be noted that the screen snaps and setting options in this chapter are for your references only. The actual setting screens and options on your Notebook may be different because of BIOS update.

Control Keys

You can use only the keyboard to control the cursor in the BIOS Setup Utility.

Press left arrow to select one menu title.	Press right arrow to select one menu title.
Press up arrow to select one item under the menu title.	Press down arrow to select one item under the menu title.
 Increase the setting value or make changes.	
Decrease the setting value or make changes.	
 1) Open the selected item to change setting options. 2) Bring up a sub-menu when available.	
In some items, press this key to change setting field.	
Bring up help screen providing the information of control keys.	
1) Exit the BIOS Setup Utility. 2) Return to the previous screen in a sub-menu.	

BIOS Setup Menu

Once you enter the BIOS Setup Utility, the Main Menu will appear on the screen. Select the tags to enter the other menus.



Main Menu

Show system overview information about BIOS version, CPU features, memory size and setting of system time and date.

Advanced Menu

Adjust the advanced settings, such as power consumption, USB/ PCI devices, of the notebook in order to achieve a better performance.

Security Menu

Install or clear the password settings for supervisor and user.

Boot Menu

Set up boot type and boot sequence.

Exit Menu

Save or discard the changes before leaving the BIOS Setup Menu.

INFO

The BIOS items and figures shown here are for reference only.

Main Menu



- **System Date**

  This item allows you to set the system date. The date format is [day:month:date:year].

Day	Day of the week, from Sun to Sat, which is determined by BIOS (read-only).
Month	The month from 01 (January) to 12 (December).
Date	The date from 01 to 31.
Year	The year can be adjusted by users.

- **System Time**

  This item allows you to set the system time. The system clock will go on no matter you shut down the PC or get into sleep mode. The time format is [hour:minute:second].

- **Serial_ATA/ eSATA**

  These items display the types of the SATA/ eSATA devices installed in the notebook. Press **[Enter]** to bring up a window showing the detailed information of the device, including the device name, vendor, LBA mode, PIO mode and more.

- **System Information**

  This item provides the information about the firmware, processor, and system memory.

Advanced Menu



- **PowerNow**

  This item allows you to enable or disable **PowerNow** function. When set to **Enabled**, the system always operates in a conserve power mode. If you want to optimize the processor, set this item to **Disabled**, so that the processor's speed will vary depending on the use of your operating system and applications. Default setting is set to **Enabled**.

- **PCI Latency Timer**

  This item controls how long each PCI device can hold the bus before another takes over. When set to higher values, every PCI device can conduct transactions for a longer time and thus improve the effective PCI bandwidth.

  For better PCI performance, you should set the item to higher values.

  Setting options: **32, 64, 96, 128, 160, 192, 224,** and **248**.

- **Legacy USB Support**

  Selecting **Enabled** allows users to use USB devices, such as mouse, keyboard, or portable disk, in DOS system; or allows users to boot the system by USB device. Setting options: **Enabled**, **Disabled** and **Auto**.

- **AHCI Mode (Advanced Host Controller Interface)**
  Use this item to enable or disable the AHCI Mode. Setting options: **Disabled** and **Enabled**.

Security Menu



- **Change Supervisor Password**

  When this item is selected, a message box shall appear on the screen as below:

  ```
  Enter New Password
  ```

  Type a maximum of eight-digit password and press **[Enter]**. The password typed now will replace any previously set password from CMOS memory. You may also press **[ESC]** to abandon new password setting.

  When the Supervisor Password is set, new items **Change User Password** and **Password Check** will be added in the menu.

  Select **User Password** to give or to abandon password.

  Note that **Supervisor Password** field allows users to enter and change the settings of the BIOS SETUP UTILITY, while **User Password** field only allows users to enter the BIOS SETUP UTILITY without having the authorization to make any change.

The **Password Check** item is used to specify the type of BIOS password protection that is implemented. Settings are described below:

Setup	The password is required only when users try to access to BIOS SETUP UTILITY.
Always	The password is required every time when the Notebook is powered on or when users try to access to BIOS SETUP UTILITY.

To clear a set Supervisor Password/ User Password, just press **[Enter]** under **Change Supervisor Password/ Change User Password** field when prompted to enter the password. Please note that when Supervisor Password has been cleared, User Password will be cleared as well. A message box pops up confirming password will be disabled. Once the password is disabled, users can enter the BIOS Setup menu without entering password when the system is rebooted.

Boot Menu

- **Boot Settings Configuration**

  Configure settings during system boot.

- **Boot Device Priority**

  These items showing the sequence of boot devices where BIOS attempts to load the disk operating system.

Exit Menu


BIOS SETUP UTILITY
Main Advanced Security Boot Exit
Exit & Save Changes
Exit & Discard Changes
Discard Changes
Load Setup Defaults
Exit system setup after saving the changes.
F10 key can be used for this operation.
↔ Select Screen
↑↓ Select Item
Enter Go to Sub Screen
F1 General Help
F10 Save and Exit
ESC Exit
v02.61 (C)Copyright 1985-2006, American Megatrends, Inc.

- **Exit & Save Changes**

  Save the changes you have made and exit the utility.

- **Exit & Discard Changes**

  Exit the utility without saving the changes you have made.

- **Discard Changes**

  Abandon your changes and reload the previous configuration before running the utility.

- **Load Setup Defaults**

  Select this item to load the default settings.